







Instructions

Changing from Coil trailer to reel trailer





9. Slide swing out arm over pipe bracket



10. swing arm into position

11. drop pin in hole (may have to adjust hole plate)

12. tighten bolts in hole plate